

Trail Clamp Fitting Instructions

N.B The exact Trailclamp model may vary from the illustration however the fitting procedure remains the same.



1. Insert the key, rotate ½ turn and gently pull on the key until the lock pops out. Remove the return arm.

With the tyre valve positioned away from the tubes that are welded to the inside of the Trail Clamp disc, offer the Trail Clamp up to the wheel at a 90 degree angle so that the short arm hooks behind the wheel.



2. With the short arm hooked behind the wheel move the long arm of the Trail Clamp towards the wheel so that it lies flat against the tyre.



3. With the keys removed and the lock in the unlocked position, slide the return arm into the Trail Clamp and around the rear of the tyre. Once tight against the tyre push the lock into the nearest available hole.



4. To remove the clamp, insert the key, rotate ½ turn and gently pull on the key until the lock pops out.

For further guidance view our fitting video at www.bulldogsecure.com

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.

Tel: 01952 728171

Email sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray the lock mechanism with WD40 (or equivalent) minimum every four months.