


WARNING:

1. For maximum security you are advised to site the post on a concrete or tarmacadam site - 'NOT ON LOOSE GROUND'.
2. Always remember to replace a ground socket metal cover when the post is removed.
3. Fit protective cap to Lock Bolt to prevent ingress of dirt.



Fitting

1. Mark position on ground for the socket.
2. Excavate the hole to take socket and ground lock tube.
3. Place the ground socket into the hole and ensure that the socket is level with the top of the hole.
4. Mix the concrete taking care to make sure the mix is not too wet as fairly firm mix is essential to support the ground lock tube.
5. With the socket in place half fill the hole tamping the concrete around the base.
6. Insert the lock bolt through the eye welded to the post and lock into the ground lock tube.
Fit the plastic cap to prevent concrete and dirt damaging the lock. Now place the post into the socket, continue to fill around the post and ground tube ensuring the ground tube is level with the top of the ground socket and post is level and upright. For safety reasons no ground components should protrude.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.
Tel: 01952 728171
Email sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.