

Shroud Assembly



C Coupling Adaptor

How To Lock.

1. Insert the key and turn a quarter of a turn anticlockwise to release C coupling adaptor.
2. Gently tip the assembly forward so the adaptor slides out.
3. Push the C coupling complete with adaptor onto the male connector of the red airline of the trailer.
4. Push the lock assembly over the coupling and lock in position using the key.

How To Unlock.

1. Hold the outer shroud.
2. Insert the key and turn a quarter of a turn anticlockwise.
3. Withdraw shroud.
4. Remove C coupling adaptor and lock back in place in the shroud.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.
Tel: 01952 728171 Fax: 01952 728117
Email sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.